
usb_next
usb_nextpkt
usb_mbuf
ifq_head
ifq_tail
usb_ifqueue
free_q
used_q
usb_fifo_methods
methods
usb_symlink
symlink
usb_fs_endpoint
fs_ep_ptr
usb_fifo
hdr
udev
usb_proc_msg
usb_done_msg
xroot
done_m
dma_parent_tag
usb_dma_parent_tag
usb_process
done_p
usb_xfer_root
done_q
bus
tag_parent
xfer_page_cache_end
xfer_page_cache_start
attach_msg
detach_msg
explore_msg
reset_msg
resume_msg
shutdown_msg
suspend_msg
usb_bus_msg
methods
usb_bus
power_wdog
usb_page_cache
usb_callout
devices
ecomp
intr_q
usb_endpoint_ss_comp
_descriptor
buf_fixup
frbuffers
timeout_handle
edesc
ctrl_ep
endpoints
ep_curr
curr
usb_xfer_queue
endpoint_q
usb_endpoint
wait_queue
fs_xfer
xfer
usb_xfer_flags_int
flags_int
usb_xfer
ctrl_ep_comp_desc
ctrl_xfer
dma_page_ptr
bsd_xfer
usb_cdev_privdata
curr_cpd
usb_page
dma_page_cache_ptr
xfer_page_cache_ptr
curr_xfer
usb_host_endpoint
endpoint
desc
usb_host_interface
altsetting
cur_altsetting
iface
usb_pipe_methods
usb_interface_descriptor
idesc
usb_interface
usb_endpoint_descriptor
flags
dma_page_ptr
dummy
cs_msg
usb_bus_methods
ctrl_ep_desc
usb_xfer_flags
usb_udev_msg
usb_device_qualifier
usb_device_statistics
stats_cancelled
stats_err
stats_ok
parent_hs_hub
parent_hub
usb_device
usb_config
curr_setup
dma_tag_p
usb_setup_params
parm
usb_temp_config_desc
ppConfigDesc
usb_temp_device_desc
udq
tdd
usb_power_save
pwr_save
usb_template_ptr
usb_temp_data
usb_dma_tag
hubudev
usb_hub
hub
ports
usb_device_descriptor
udd
ddesc
scratch
usb_device_scratch
temp_setup
usb_temp_setup
usb_port
usb_device_flags
usb_hw_ep_scratch
hw_ep_scratch
cdesc
cd
linux_udev
usb_config_descriptor
ifaces
ep
ep_max
usb_hw_ep_scratch_sub